

V35047

INSTALLATION MANUAL - CHANNEL LOK II OVAL POOLS POOL MODEL - PRETIUM GLX & PIB





ABOVE GROUND POOL SAFETY PLEASE READ BEFORE INSTALLATION

WARNING FAILURE TO HEED THESE WARNINGS CAN RESULT IN PERMANENT INJURY, PARALYSIS FROM A BROKEN NECK, ELECTROCUTION OR DROWNING. THIS POOL IS NOT DESIGNED FOR DIVING OR JUMPING! DANGEROUS INJURY CAN RESULT, SHALLOW WATER!

9. KEEP OFF TOP LEDGES

10.POOL COVER SAFETY

11.ELECTRICAL HAZARD

12.SAFETY ROPE & POLE

13 POOL CHEMICALS

blunt or hook end available at pool side in case of emergencies.

when storing, handling and dispensing pool chemicals.

14.CHECK FOR DAMAGE

15. POOL PARTS

for your replacement parts.

swimming pool professional.

during electrical or rain storms.

Do not walk on top ledges. They can be slippery and they are not a walkway.

The cover must have a tamperproof locking retainer cable that positions the cover around the pool wall and keeps it securely in place. Never allow anyone, especially small children on the

cover. Asphyxiation or drowning could result. When purchasing any pool cover, please consult a

Never touch or attempt to service electrical equipment, including the filter when your body and/

or the ground is wet. Electrocution or permanent injury due to high voltage (120V AC) could

result. The pool should be bonded in accordance with Section 680-26 of the National Electical

Code. For further assistance contact your dealer or a local licensed electrician. Do not use pool

Keep a safety rope 1/4" by 50" with a flotation buoy with an outside diamter of 15". Have ac-

cessible in a prominent area by your pool. Keep a pole not less that 16 feet (4,88m) long with a

Do not place chlorine, chlorine tablets or sticks directly into skimmer, or winterize your pool with

struction will void all component warranties. Always follow Chemical Manufacturer's instructions

Periodically check your pool and ladder components for damage and wear. Be sure all screws

are in place. Replace all damaged or worn components and tighten all screws before you use

Never modify the pool or accessories, or remove or drill holes in the pool, deck or ladder com-

ponents unless instructed. Your pool wall is made of thin metal, there is an inherent cut hazard

with metal so use gloves during installation. Always use Original Equipment Manufactured parts

the pool, deck or ladders. At first sign remove rust and touch up immediately.

liquid chlorine. Damage to the skimmer, pool liner and filter will result. Failure to obey this in-

Your pool contains a large quantity of water, and is deep enough to present inherent dangers to life and health unless the following safety rules are strictly observed. First-time users run the highest risk of injury. Make sure everyone understands. To insure your pool is used safely you **must** observe the following safety precautions:

1. NO JUMPING OR DIVING

The top rail of your pool is not a walkway and must not be used for jumping or diving. Do not permit jumping or diving into the pool from a deck or the top rail of the pool. Diving or jumping into the pool can result in serious injury.

2. NEVER USE THE POOL ALONE

Never permit the pool to be used unless it is attended by at least one person other than the bather. Someone should always be available to lend assistance in an emergency.

3. NEVER LEAVE CHILDREN UNATTENDED

Never leave a child alone and unsupervised in or near the pool—not even for a second. There is no substitute for constant adult supervision.

4. NO ROUGH PLAY

Do not permit "rough-playin" in and around your pool. Surfaces can become slippery and hazardous when wet.

5. LIGHT THE POOL AT NIGHT

If the pool is used after dusk, adequate lighting must be provided. Illumination in the pool area must be sufficient to clearly judge pool depth and all features in and around the pool. For lighting recommendations, consult your local licensed electrical contractor

6. RESTRICT ACCESS TO THE POOL

Do not leave chairs or other furniture beside the pool that could be used by a child to climb up into the pool. Ladders must be removed whenever the pool is unattended. A fence with a lockable gate around the pool or yard is strongly recommended and may be required by law in some jurisdictions.

7. NO ALCOHOL OR DRUGS

Never drink alcoholic beverages or use any intoxicants which could hinder your judgment and reflexes.

8. KEEP YOUR POOL CLEAN AND SANITARY

Your filter system will remove suspended particles from the water and the surface skimmer will remove insects, leaves and other debris from the water surface. Use the correct pool chemicals as directed to destroy harmful bacteria and prevent formation of algae. Remember, unsanitary water is a serious health hazard.

FOLLOW ALL SAFETY INSTRUCTIONS

Read and follow all safety instructions packaged with pool, ladder, deck or any other accessory. Additional pool safety publications can be obtained by contacting: The Association of Pool & Spa Professionals (www.apsp.org)

REMEMBER WATCH CHILDREN

IMPORTANT NOTICE READ BEFORE INSTALLATION!

The safety stickers must be installed as per following instructions. Failure to properly install warning labels will void warranty. Failure to mount these safety labels may subject you to substantial liability in case of injury. These warning are not to be removed under any circumstances! If they become discolored or fall off please request replacements which will be sent at no charge.







PLACE SIGN ON LINER ABOVE WATER LINE, OPPOSITE EN-

TRY TO POOL



PLACE SIGN ON WALL NEXT TO POOL ENTRY




SECTION General Instructions - Channel Lok II Oval Pools

Ground Preparation

Read all instructions completely before you begin.

A. Determine a Location for your Pool

- 1. The Terrain
 - Pay special attention to choosing the right location for your pool:
 - Choose a large area, as flat and level as possible and well drained.
 - Choose a spot on dry, firm earth do not install the pool on concrete, asphalt, tar paper, sand, gravel, peat moss, wood or chemically treated soil.
 - Check with your pool dealer to see if Nut Grass grows in your area.This type of grass may grow up through your pool liner. Your dealer will be able to advise how best to treat the site.
 - Sloped areas will need to be made level by digging away high spots, not by filling low spots—be prepared to hire earth-moving equipment if necessary.





Important Note:

Ground preparation is one of the most important steps in the installation process. A proper foundation will ensure the rest of the pool assembly goes smoothly and that no problems will occur when the pool is filled with water.

Open all of the frame cartons and read all of the instructions before you begin. Be sure to read Section 2 and get a complete overview of the pool base and buttress assembly before starting the ground preparation.



2. Things to Avoid

Do not locate your pool near or on any of the following:

- Overhanging tree branches.
- · Overhead wires and clotheslines.

· Buried pipes and wires-contact your gas, electric and telephone utilities to find buried pipes and wires before you dig.

- Hilly and uneven terrain.
- · Areas with poor drainage.

• Grass, stones and roots. Grass will rot underneath the pool liner, and stones and roots will damage the pool liner.

· Areas recently treated with oil-based weed killers, chemicals or fertilizers.

3. **Plan Ahead**

• Will you be adding an adjacent deck later? Be sure to leave room.


• Will you be using pool accessories or other appliances that need electricity or gas? Locate your pool near these services or plan to have them installed later by a licensed contractor.


4. **Tools Needed**


Make sure you have the necessary tools and materials before beginning your installation:

• Waterhose

- Hammer
- Tape Measure • SprayPaint
- Level Screwdriver
- Straight wood plank Rake
- String & Stakes • Duct tape
- Wheelbarrow • Mallet
 - Compactor
- Wrench • Vacuum cleaner
- Cement blocks (5cm x 20cm x 40cm / 2"x8"x16") (optional)
- Material that provides a permanent base (ex. crushed stone)
- Fine Sand (void of debris)
- 2 x Plywood (60cm x 120cm / 2ft x 4ft)
- Pool Carpeting (optional)
- Polyethlyne Plastic Sheeting
- Vinyl covered hooks to hold the wall steady











When locating the centre of the pool, be sure to take into consideration any structures (deck, patio, house) or relevant items (change rooms, gazebo, etc.)

that the pool may need

ensure that the pool is in


the most visual pleasing location for your

to line up with and

property.


Shovel

B. PARTS LISTING - EXPLODED VIEW



PARTS LISTING - EXPLODED VIEW

Pretium GLX STR PPREGLX-CH52SSSTSSFB0 Channel Lock



PARTS LISTING - CONTENT LIST

Produc	ct Description:	Pretium	GLX Ova	I			Revised Sept.2	013
Produc	ct Code:	PPREGLX-CH52SSSTSSFB0						
		Quantity required for installation (by pool size)						
INDEX#	DESCRIPTION	PARTS#	LENGTH	1218	1224	1524	1530	1833
7	Top Ledge Curve	1450872	45-15/32"	8	8			
		1450873	56-27/32"			8	8	10
	Top Ledge Trans	1450874	47''		4			
		1450875	58-1/4''	4		4	4	4
	Top Ledge Str Side	1450876	47-1/4''		4	2		
		1450877	58-3/4''				4	4
1	Upright	1440512	51-1/2"	10	10	10	10	12
4	Top Plate	1320102		10	10	10	10	12
17	SideTop Plate	1320160		2	6	4	6	6
2	Bottom Plate	1320101		10	10	10	10	12
n/a	Slotted tube Connector (steel)	1470108		10	10	10	10	12
n/a	Slotted tube Connector - side (resin)	1470087		2	6	4	6	6
n/a	Round Coping	1382480	47''	13	16	17	20	23
19	Rail Support	1490494			4	2	4	4
5	Slotted tube	1470096	44''	8	8			
	Slotted tube	1470097	55-1/2"			8	8	
	Slotted tube (Yellow)	1470098	55-1/4"	4				6
	Slotted tube(Green)	1470100	55-1/2"			4	8	12
	Slotted tube (Blue)	1470104	44-1/8''		4		-	
	Slotted tube (White)	1470105	44-1/8''		4	2		
18	Bottom Rail	1460048	44-5/8''	8	8			
	Bottom Rail	1460049	56"	-	-	8	8	
	Bottom Rail (Yellow)	1460050	56"	4			0	6
	Bottom Rail (Orange)	1460052	56-1/4"	•		4	4	8
	Bottom Rail (Blue)	1460138	44-5/8''		4			0
	Bottom Rail (Green)	1255624	11 5/ 6				4	4
	Bottom Rail (White)	1253024	44-5/8''		4	2		
9	Ledge cover	1490837	44 5/0	12	16	14	16	18
10	Ledge cover - lower, round end only	1490849		12	10	10	10	10
10	Ledge cover - lower, for buttress only	1490850		2	6	4	6	6
3,6,8	Hardware Pack (Qty 59)	1184299		۷	0	-	0	1
3,0,0	Hardware Pack (Qty 77)	1184300		2	2	2	2	1
	Hardware Pack (Qty 77)	1184298		2	2	2	2	1
n/a	DVD	36877		1	1	1	1	1
11/4	Upright	1440514		2	6	4	6	6
12	Diagonal	1440314		2	6	4	6	6
12	Hold Down Plate	1320162		2	6	4	6	6
10	Diagonal Bracket			2	6	4	6	6
	-	1320152				4	6	
15	Oval bottom Plate	1320154		2	6	4 2	<u>6</u> 3	6
	Hardware Pack	1184292		1	3	2	3	3
13	Strap Section	1510132		1	3	2	2	
		1510133				2	3	
	NA/- 11	1510134	┝──┤	4				3
	Wall Wall joiner bar	11823		1	1 2	1 2	1 2	1

C. Prepare the Foundation of your Pool

your pool size on the last pages of this Section 1.

К 🛛

Μ

12 x 18 (3,66m x 5,49m)

a. Choose the drawing that matches your pool size from the five plan drawings below.

This drawing will have all of the necessary dimensions for the ground preparation

instructions that follow. NOTE: Please be sure to use your pool's footprint for

XJ

1. Choose the Correct Ground Preparation Drawing a Choose the drawing that matches your pool size from

Important:

When locating the centreline of the pool, **be sure** to take into consideration any structures (deck, patio, house) or relevant items (change rooms, gazebo, etc.) that the pool may need to line up with and ensure that the pool is in the most visual pleasing location for your property.

12 x 18 (3,66m x 5,49m) Oval Pool Dimensions

- R 76-1/2" (193 cm)
- S 88-1/2" (224 cm)
- L 28" (72 cm)
- M 28" (72 cm)
- P 56" (143 cm)
- W 96" (244 cm)
- X 72" (183 cm)
- Y 80-1/2" (204 cm)
- Z 100" (254cm)

12 x 24 (3,66m x 7,32m) Oval Pool Dimensions R 74-1/4" (188 cm) S 86-1/4" (218 cm) L 67-7/8" (170 cm) M 20" (51 cm) N 48" (122 cm) P 135-3/4" (343 cm) W 96" (244 cm) X 72" (183 cm) Y 86-1/2" (219 cm) Z 117-1/2" (297 cm)


× F G 7 W Y Х R S B L ^LCentreline Centre Point Pool Wall Pool Area D E Clearance Area -Measuring Stakes C Support Trenches ΗX 🛛 I 12 x 24 (3,66m x 7,32m) p -К 🖾 ΧJ M N G E Х R s 6 B А L ^LCentreline Centre Point Pool Wall Pool Area D Clearance Area Measuring Stakes Support Trenches Η区

Observe all Safety Rules.

No Diving or Jumping.

1-6

Η 🛛 No Diving or Jumping. 🥙 Observe all Safety Rules.



15 x 30 (4,57m x 9,14m)

15 x 30 (4,57m x 9,14m) **Oval Pool Dimensions** R 93" (236 cm)

S 105" (266 cm)

L 84-5/8" (214 cm) M 25-1/4" (64 cm)


N 59-1/2" (150 cm)

W 114" (290 cm) X 90" (229 cm)

Z 142" (360 cm)

P 189-1/4" (480 cm)

Y 107-7/8" (272 cm)



15 x 24 (4,57m x 7,32m) **Oval Pool Dimensions**

R 93" (236 cm)

S 105" (267 cm) L 49" (125 cm)

M 25" (64 cm)

N 48" (122 cm) P 96" (244 cm)

W 114" (290 cm)

X 90" (229 cm)

Y 93-1/8" (236 cm)

Z 124" (315 cm)

1-7

18 x 33 (5,49m x 10,05m) Oval Pool Dimensions R 110-1/2" (279 cm)


S 122-1/2" (310 cm)

- L 87-7/8" (221 cm)
- M 25-1/2" (64 cm)
- N 59-1/2" (150 cm)
- P 169-3/4" (429 cm)
- W 132" (335 cm)
- X 108" (274 cm)
- Y 123-1/4" (312 cm)
- Z 157" (399 cm)

\diamond

Important: Determine the location of your pool. Make sure you have the proper distances away from any adjacent structures (i.e. fences, house etc.). Contact local authorities for this information and any additional requirements governing the installation of a pool in your area.

By using the distances provided by local authorities and adding them to dimension S from the drawings above, you can calculate the location of the centreline of the pool.




2. Mark out the Area

Pool Size


than the pool.


Pool Size

a. Drive two pegs (A) and (B) into the ground. These pegs will both be on the centreline of your pool. Choose the right distance between them from the chart below. Note: Distance A to B is equal to dimension P on the previous ground preparation drawings.



c. Join the two pegs (A) and (B) with a piece of string. Use this string as a guide to paint your centreline on the ground with the can of spray paint.






Observe all Safetv Rules.


Important:


Measure carefully to make sure the centre stake (C) is in the correct location, **exactly**

halfway between pegs (A) and (B). You will use stake (C) later as a reference point for other measurements.

- d. Drive a flat-topped stake (C) exactly halfway between the two pegs (A) and (B) on the centreline. Stake (C) will mark the exact centre point of your pool. The stake must be at least 1" (25 mm) square and 6" (15 cm) long. Drive it down flush with the ground surface.
- e. Replace the two pegs (A) and (B) with two more flat-topped stakes. Drive them down flush with the ground surface.
- f. Join the two circles with straight lines to make an oval. Use pegs and a piece of string as a guide for the can of spray paint.
- g. Mark areas along both straight sides of your oval. Use pegs and string as a guide for the can of spray paint to mark straight lines. Use the chart below to find the correct **width W** from the centreline of the pool. The ends of the side areas should line up squarely with stakes (A) and (B).







ſ	Pool Size	Distar
	12' x 18' (3,66m x 5,49m)	
	12' x 24' (3,66m x 7,32m)	
	15' x 24' (4,57m x 7,32m)	
	15' x 30' (4,57m x 9,14m)	
	18' x 33' (5,49m x 10,05m)	
I	- · · ·	

Distance from Centreline for Side Area W 96" (244cm) 96" (244 cm) 114" (290cm) 114" (290cm) 132" (335cm)





3. Remove the Sod

- a. Remove all sod and plants from the area.
- b. Remove any sticks, stones and roots from the area.

4. Make the Area Flat and Level


a. You will use a 2-by-4 to help level the pool foundation area. Choose the length of straight 2-by-4 you need for your pool from the chart below.





Length of plank 2-by-4 (5cm x 10cm)
84" (213cm)
84" (213 cm)
102" (259cm)
102" (259cm)
120" (305cm)

- b. Adjust the height of the stake (A, B or C) that is located at the **lowest** end of the pool area by hammering it down until it is **exactly** level with the ground. Place a carpenter's level on a 2-by-4 and place the board across the three stakes to make sure the tops are exactly level with each other. Adjust the other two stakes down as needed.
- c. Nail one end of the 2-by-4 to the top of the stake where the level of the pool foundation is **lowest.** Drill a hole for the nail in the **centre** of the top of the stake first and make the hole big enough so the nail is a little loose and can be removed without moving the stake. Mark the centre of the stake before you drill the hole by marking lines diagonally from opposite corners (see diagram 16). Use a nail long enough to hold the end of the 2-by-4 to the stake while you rotate it in a circle.





Remember:

Your pool must be


perfectly level.


perfectly level. Take


the time you need to be


sure your foundation is

- d. Put a carpenter's level on the 2-by-4 and swing the board in a circle to find the high and low spots.
- e. Remove all the high spots with a shovel, hoe or rake. To make sure your pool is stable, compact the ground well before adding the sand. Be prepared to hire earth moving equipment if you need to level a large area. Remember, your pool must be level across the diameter of the pool
- f. Small dips and hollows may be filled in, but the soil must be hard-packed with a tamping tool.
- g. Remove the 2-by-4 from the stake and nail it to the next stake on the centreline.
- h. Repeat the last five steps until the whole oval area is level. Take your time and make sure the area is **perfectly level.** If necessary, adjust the height of each stake and keep scraping away soil 19 until the entire area is level.
- i. Take material such as rock dust or fine mortar that can conform a solid, permanent base and deposit this material around the rim of the basin. The material used should be spread around the perimeter of the pool to a width of 24" (60cm) and a thickness of 2" (5cm).
- j. Recheck the outer perimeter of the oval shape, where the pool wall will be placed. Compact the ground and make sure there are no high or low spots. The bottom edge of the pool wall must rest flat on the ground and have no gaps under it.












Remember:

The outer 12" (30 cm) of the cleared oval area must be perfectly flat. The bottom edge of the pool **must** rest flat on the ground and have no gaps under it. Take the time you need to be sure this area is perfectly flat and level.

5. Add Corner Stakes

- a. Prepare eight corner stakes (D), (E),
 (F) & (G), and (H), (I), (J) & (K) by marking the centre point of each stake the same way as in step 4(c).
- b. Drive the eight corner stakes into the ground. Drive them down flush with the ground surface. Locate each stake exactly by using the measurements for your pool in the chart below. Be sure to measure using the centre point of each stake.




c. Tie strings between stakes (H) and (I) and between (J) and (K).

Pool Size	Distance X	Distance Y	Distance W	Distance Z
12' x 18' (3,66m x 5,49m)	72" (183cm)	80-1/2" (204cm)	96" (244cm)	102-1/2" (260cm)
12' x 24' (3,66m x 7,32m)	72" (183 cm)	101-3/4" (258cm)	96" (244cm)	120" (305cm)
15' x 24' (4,57m x 7,32m)	90" (229cm)	105" (267cm)	114" (290cm)	126-1/8" (320cm)
15' x 30' (4,57m x 9,14m)	90" (229cm)	127-1/4" (323cm)	114" (290cm)	145-1/4" (369cm)
18' x 33' (5,49m x 10,05m)	108" (274cm)	140-5/8" (357cm)	132" (335cm)	159-3/4" (406cm)

6. Prepare Buttress Trenches

- a. Locate the first trench by measuring the **distance M** from the centre of stake (H) to the **centreline** of the trench. Use the chart below to find the right distance M for your pool.
- b. Place a stake in the ground on the edge of the cleared area at distance M, underneath the string added in step 5(c).




Pool Size	Distance from Stake to Trench Centreline M	Distance between Trenches N
12' x 18' (3,66m x 5,49m)	36" (91cm)	n/a
12' x 24' (3,66m x 7,32m)	24" (61 cm)	48" (122cm)
15' x 24' (4,57m x 7,32m)	30" (76cm)	48" (122cm)
15' x 30' (4,57m x 9,14m)	30-1/2" (77cm)	59-1/2" (151cm)
18' x 33' (5,49m x 10,05m)	30-1/2" (77cm)	59-1/2" (151cm)




Instead of wooden corner stakes, you can use 12" (30 cm) spikes.

c. Repeat steps (a) and (b) to locate the next trench along the side of the pool. Measure the distance N from the centreline of the first trench to the centreline of the next trench. Use the chart on previous page to find the right distance N for your pool. (Important Note: The 12 x 18 pool has only one trench per side; the 15 x 24 pool has two trenches per side; the 12 x 24, 15 x 30 and 18 x 33 pools all have three trenches per side.)




- d. Place another stake in the ground on the edge of the cleared area at distance N, underneath the string added in step 5(c).
- e. Repeat steps (a) to (d) for the other side of your pool.
- f. Tie a string between each pair of stakes on opposite sides of the cleared area (the stakes added in steps (b) and (d), above) to mark the centreline of the trenches.
- g. Mark the centrelines along each string with the can of spray paint.
- h. Recheck your measurements. Make sure the distances M and N **exactly** match the distances given in the chart above (see also diagram 26) and that the centrelines for the trenches are **exactly parallel.**
- i. Remove the strings. (**Note:** Keep the strings. They will be temporarily replaced later, after the trenches are dug out, to help you double-check that the trenches are parallel.)






() Caution:

Make sure there is adequate drainage in the bottom of each trench and along the sides of the pool area. There must be adequate drainage for a safe and secure pool foundation.



o. Recheck the distances between the patio stone and make any adjustments you need to make sure the spacing is exactly right. Refer to page 1-10, Step 6 for measurements.


• See the drawing on the next page for an overview of all the parts used to install the buttresses, uprights and base rails.




HARDWARE FOR CHANNEL LOK-II POOLS				
DESCRIPTION	ACTUAL SIZE	TOOL REQUIRED FOR INSTALLATION		
SELF TAPPING SCREW #12 X 1/2 INCH (1,2cm) LONG	()	PHILLIPS NUMBER 3 SCREWDRIVER OR RED HANDLE #2 ROBERTSON SCREWDRIVER		
SERRATED FLANGE HEXAGON NUT 1/4-20 (0,6cm)	© E[7/16 INCH (1,1cm) WRENCH OR SOCKET		
HEXAGON HEAD BOLT 1/4-20 X 3/4 INCH LONG (0,6cm x 1,9cm)		7/16 INCH (1,1cm) WRENCH OR SOCKET		
HEXAGON HEAD BOLT 1/4-20 X 2 1/4 INCH LONG (0,6cm x 5,7cm)		7/16 INCH (1,1cm) WRENCH OR SOCKET		

7. Strap Preparation for the Buttresses


- a. Gently flatten any kinks or bends out of the straps (key 8).
- b. Lay the strap across the levelled area for the pool as shown in diagram 30. Centre the strap over the patio stone as shown in diagram 30.



Space the end of the strap 2-1/4" (6 cm) from the outside edge of the patio stone.




- c. Fasten one diagonal bracket (key 4) to the strap (key 8) using four 3/4" long bolts (key 21) and nuts (key 10). Make sure the angled part of the bracket is facing the correct direction as shown in diagram 32. The surface that the diagonal bracket is fastened to will be the top of the strap.
- d. Repeat steps (a) to (c) for the other end of the strap.
- e. Repeat steps (a) to (d) for the other straps.






8. Installing the Upright

- a. Using a straight edge (you can use one of the hold down plates), drag along the top edge of the strap to ensure the ground is exactly even and level with the strap (the area 24" (61 cm) beyond each side of the strap must be level too). If it is not level, spread some crushed limestone (or equivalent) on the ground. Stand on the strap and tamp it down hard with a tamping tool. Verify the ground is level to the strap by running the straight edge along the top edge of the strap. Repeat this step until the ground is level.
- b. Gently lift the strap and insert four 3/4" long bolts (key 21) into the holes closest to the centre of the pool. Ensure the bolt heads are facing the ground. Lay the strap back down on the ground and place the hold down plate and base plate (as shown in diagram 36) over the bolts protruding from the strap and fasten the nuts to the bolts and tighten.




- Caution: Failure to properly install and tighten all of the bolts and nuts may void the warranty on your pool.
- c. Fasten one upright (key 1) to the base plate using three 3/4" long bolts (key 21) and nuts (key 10). Make sure the bottom end of the upright is fastened to the base plate. The bottom end of the upright has three large holes which are used to fasten to the base plate.



- d. When you come to section 2, you will install the bottom rails, linking them to the buttresses. Make sure now that there is approximately a 1/16" (2 mm) gap under the tab at the bottom of each upright so the bottom rails slide on easily.
- e. Repeat steps (a) to (d) for the other side of the pool.


9. Install the Diagonals

a. Hold one diagonal brace (key 2) approximately horizontal, insert the four




tabs at the end **W** of the diagonal into the slots in the upright (key 1) (see diagram 39).

b. Pull upward on the inserted end of the diagonal to make the tabs slide up and lock into position in the slots. At the same time, swing the other end of the diagonal down onto the diagonal bracket (key 4) on the base channel (see diagrams 40 and 41).



(2 mm) gap





Important: Ensure all four tabs at the end of the diagonal are inserted into the slots in the upright.


- Very important: as you swing the diagonal down, make sure you apply constant upward pressure on the end of the diagonal brace with the tabs to ensure they stay fully locked in position in the slots.
- c. Fasten the bottom end of the diagonal brace to the diagonal bracket (key 4) with two 2-1/4" (57 mm) bolts (key 26) and nuts (key 10). Do not overtighten the bolts. They only need to be snug enough to ensure a secure fit (see diagram 42).
- d. Repeat steps (a) to (c) for the other side of the pool.
- e. Repeat steps (7) to (9) for the rest of the buttresses.


10. Buttress Location Verification

- a. Tie strings between stakes (D) and (E) and between (F) and (G). These will be used as a reference to make sure the buttresses are exactly lined up with each other. Stand at each corner of the pool and check the alignment of the buttresses with the strings.
- b. Jump to Section 2 and complete steps 1(a) and (b). This will allow you to install the bottom buttress rails, ensuring the correct distance between the buttresses. Important: complete only steps 1(a) to (c) for now, and then continue with step 11 below; you will complete the rest of Section 2 later.

11.Fill in the Hold Down Plates

a. Standing on the hold down plate, insert material into all open voids on the outside edges of the hold down plates until they are full. These voids are the open areas between the ground and the top edges of the hold down plate. This will prevent any low spots from forming around the hold down plates when the pool is filled with water.










Important:


After the ends of the hold down plate has been filled with material, place a sheet of plastic (approximately 15" x 15" (38cm x 38cm)) at each end of the hold down plate. This will prevent any additional material from flowing into the ends of the hold down plate that may cause low spots to form around the plates.




b. Repeat step (a) for the other hold down 45

12. Remove the strings and stakes


- a. Make sure all of the strings and stakes (except stakes (A) and (B)) are removed from the entire pool area and fill in any holes with crushed limestone (or equivalent). Leave stakes (A) and (B) in place for now; they will be used later to centre the pool wall.
- b. Measure the two intersecting axes to ensure that the two straight sections are parallel.









12 x 24 Footprint






1-25

15 x 30 Footprint





18 x 33 Footprint




Pool Component Installation Manual

Assembling the Pool Base & Side Buttresses

1. Install the Curved Bottom Rails

a. Each pool uses two, three or four different types of curved bottom rails (key 13). The rails are colour coded or stamped with a part number. Use the chart below to choose the types and quantities of bottom rails for your pool (part numbers are shown in brackets under each colour).

Pool Size	Buttress Rail	Transition Rail A	Transition Rail B	End Rail
12' x 18' (3,66m x 5,49m)	n/a	4 yellow (no. 1460050)	n/a	8 plain (no. 1460048)
12' x 24' (3,66m x 7,32m)	4 white (no. 1254424)	4 blue (no. 1460138)	n/a	8 plain (no. 1460048)
15' x 24' (4,57m x 7,32m)	2 white (no. 1254424)	4 orange (no. 1460052)	n/a	8 plain (no. 1460049)
15' x 30' (4,57m x 9,14m)	4 green (no. 1255624)	4 orange (no. 1460052)	n/a	8 plain (no. 1460049)
18' x 33' (5,49m x 10,05m)	4 green (no. 1255624)	4 orange (no. 1460052)	4 orange (no. 1460052)	6 plain (no. 1460050)







Hint:

Bring the following items onto the pool foundation **before** you start uncoiling the pool wall: the **pool liner**, some extra **brick sand** to make the cove in Step 5, and a **ladder** to climb out after the wall is assembled.

Caution: Do not attempt to install the pool wall in the wind. Wait for a calm day.



Hint:

Secure the omega stabilizer to the wall with a piece of duct tape after installation to prevent it from lifting off the wall. **Pool Component Installation Manual**


Assembling the Pool Wall & Liner

A. Assemble your Pool Wall

This section is for Round and Oval pools (ROUND POOLS ARE SHOWN).

1. Set the Pool Wall in place

- a. Wait for a calm day. Do not attempt to install the pool wall in the wind.
- b. Unpackage the coiled pool wall and stand it on a piece of cardboard or plywood at the centre of the pool. The cut-outs for the through-the-wall skimmer should be towards the top of the wall. Look for a "THIS WAY UP" label and arrow. Make sure the skimmer and water return holes are where you need them to be. The skimmer and water return holes are positioned towards the end of the pool wall. (The section before the wall started).
- c. Start uncoiling the wall, guiding the bottom edge into the curved bottom rail. The starting end of the wall must be positioned over a bottomplate, and the skimmer and return holes should be positioned where the pump and filter will be. Set lengths of Omega Stabilizer onto the top edge of the wall as you uncoil it.





Using a 2" (5 cm) piece of duct tape, tape the ends of the 6" (15 cm) metal slotted tube connector over the slotted tubes and onto the pool wall. This will prevent the slotted tubes from moving during liner installation. d. The slotted tubes (Omega Stabilizer) are colour coded or stamped with a part number. Use the chart below to choose the types and quantities of slotted tubes for your pool (part nos. are shown in brackets under each colour). Set lengths of slotted tube onto the top edge of the wall as you uncoil it and join the slotted tubes with connectors as you go, leaving a 1/2" (13 mm) gap between each. (If you have a **beaded pool liner**, set lengths of **liner retainer** on the top edge of the wall first, then the slotted tubes and connectors.)

Pool Size	Buttress Tube	Transition Tube A	Transition Tube B	End Tube
12' x 18' (3,66m x 5,49m)	n/a	4 yellow	n/a	8 plain
		(no. 1470098)		(no. 1470096)
		(no. 1470012)		(no. 14700010)
12' x 24' (3,66m x 7,32m)	4 white	4 blue	n/a	8 plain
	(no. 1470105)	(no. 1470104)		(no. 1470096)
	(no. 1470092)	(no. 1470091)		(no. 1470010)
15' x 24' (4,57m x 7,32m)	2 white	4 green	n/a	8 plain
	(no. 1470105)	(no. 1470100)		(no. 1470097)
	(no. 1470092)	(no. 1470014)		(no. 1470011)
15' x 30' (4,57m x 9,14m)	4 green	4 green	n/a	8 plain
	(no. 1470100)	(no. 1470100)		(no. 1470097)
	(no. 1470014)	(no. 1470014)		(no. 1470011)
18' x 33' (5,49m x 10,05m)	4 green	4 green	4 green	6 plain
	(no. 1470100)	(no. 1470100)	(no. 1470100)	(no. 1470098)
	(no. 1470014)	(no. 1470014)	(no. 1470014)	(no. 1470012)


 $\underline{\textcircled{}}$

Hint:

Secure the omega stabilizer connector to the wall with a piece of duct tape after installation to prevent it from lifting off the wall.



Hint: Stick a screwdriver through two of the holes to help line up the ends of the wall.








- **NOTE:** We also suggest installing vinyl-covered hooks and rope to hold the wall steady.
- e. Work around the foundation until the entire pool wall is uncoiled into the bottom rails and the top edge is covered with the omega stabilizer and connectors (and beaded liner retainers if you have a beaded pool liner)

2. Join the Ends of the Pool Wall

- a. Line up the holes in the two ends of the pool wall.
- b. To line up the holes, make the circle bigger or smaller by nudging the base plates in or out with your foot.
- c. To fasten the wall joint, overlap the two steel bars, one on the inside and the other on the outside. Tighten the mechanical screws on the inside and the nuts on the outside. Make sure there is a bolt in each hole.
- **NOTE:** When tightening the screws start from either the top and go down or vice versa. do not start a few screws from top and a few from the bottom to meet in the middle, this can cause problems later on
- d. Ensure that all bolts and all the holes are used.
- e. Cover the seam and bolt heads on the inside of the pool wall completely with 2 layers of 2" (50 mm) duct tape.







Hint:

Secure the omega stabilizer connector to the wall with a piece of duct tape after installation to prevent it from lifting off the wall.




Stick a screwdriver through two of the holes to help line up the ends of the wall.





Observe all Safety Rules.

4. Make a Cove

- a. If you are using sand, bank the sand against the wall to form a cove of 3" to 6" (7.5cm to 15cm) high and 8" to 12" (20cm to 30cm) wide at ground level. This will prevent the liner from creeping under the wall, and it will also protect the liner from any metal edges of the pool framework. THIS STEP IS NOT OPTIONAL, IT MUST BE DONE.
- b. Water the sand to compact it and use a trowel to spread it evenly.
- c. Since earth containing chemicals can cause discoloration or corrosion, it is suggested that you place polyethylene plastic sheeting under the cove around the perimeter of the wall, so no earth comes in contact with the metal. Since the presence of such chemicals is beyond the control of the manufacturer, such damage is not covered under warranty.
- d. If you are using styrofoam cove pieces instead of sand, insert them in the bottom rail and refer to the installation instructions that are provided with them.









Remember: The cove is an important part of the pool structure. Take your time to make a complete, full-size cove.



Remember: The bolt heads must be toward the inside of the pool. Cover the bolt heads with duct tape. e. A vacuum cleaner can later be used to remove the air from between the liner and the wall. This technique enables you to remove folds in the liner. However the following precautions should be taken:


Do not use an industrial vacuum cleaner which could be too powerful.


Tape the end of the vacuum hose before inserting it into the wall so as not to damage the liner.

Insert the nozzle until it is about 4" (10cm) above the cove (insert through the water return outlet or the skimmer depending on the diameter of your hose). Make sure you will be able to remove the hose later on.

Tape the hose to the wall.

f. Close the skimmer opening with cardboard and adhesive tape so that the suction of air works better..








No Diving or Jumping. Observe all Safety Rules.

B. Install your Pool Liner

- 1. Set the liner in place
 - a. Open the carton. **Do not** use anything sharp to open the carton.
 - b. Unpack and unfold the liner and spread it out in the sun to warm it up. Inspect all the seams and surfaces for holes.
 - c. Remove your shoes to avoid damaging the base or tearing the liner.
 - d. Spread out the liner, smooth side down. Unfold the liner from the centre of the pool toward the sides.
 - e. Use the liner's bottom seam(s) as a guide and make sure the seam(s) are parallet to the straight sections and to the imaginary line which links points A and B in the illustration 16a. It is recommended that you begin installing the liner in a round section.
 - f. Use the liner's vertical seam as a gide and make sure the sea is vertical and perpendicular to the wall and bottom.
 - g. Make sure the seam between the wall and bottom is centred on the cove.
 - g. Smooth out all the wrinkles in the bottom. Do not leave any space between the liner and cove.







If possible, unfold the liner on the grass one to two hours before installation. **Be careful** not to leave

hours before installation. **Be careful** not to leave the liner too long or you may damage the grass.



The liner is generally smaller than the support structure of the pool. It will stretch more easily when warm. It is important that the liner is installed on a warm sunny day.

\bigcirc

Important: This step applies only if you have an Overlap Liner. See next page for Beaded Liner or V-Bead Liner.


\diamond


Important: Do not trim off the excess


liner. (If the liner ever needs to be removed, trimming the liner will make re-installation very difficult.) Instead, roll up any excess liner and tape it in place near the top of the pool wall.


2. Fasten the Liner in place (Overlap Liner only)

- a. Starting at the liner wall seam, hang the liner over the wall making sure that the seam is straight up and down, perpendicular to the floor. (Remove stabilizers gradually as you fold the liner over the top of the wall.)This will assure you that the liner begins going over the wall straight.
- b. As you put the liner over the wall you can secure it by using the plastic coping strips to keep it in place. If you end up with excess material, continue around the pool, pulling excess liner evenly, and distribute over the wall until the excess is gone.
- c. Fasten the liner to the top of the wall with plastic coping. Let the liner hang slack for now. Do not pull the liner tight.
- NOTE: Some liners may fit very tightly, it is better to install uprights, top plate and top ledge before going onto next step. See Section 4.
- d. Turn the vacuum cleaner on and push the liner outward with your feet to iron out any wrinkles. Once finished, turn off vacuum cleaner.
- e. Start filling the pool with water. As the pool fills, work out all the wrinkles and smooth the liner to the wall. Remove the plastic coping around the top edge of the wall one piece at a time and adjust the liner. Keep smoothing out the wrinkles.
- f. After all the wrinkles in the liner are removed, trim any extra length of plastic coping so there is no overlap.
- g. Roll up any excess liner hanging below the plastic coping and tape it in place near the top of the pool wall. Important: Do not trim off the excess liner.










- 3. Fasten the Liner in place (HUNG/J or V-BEAD LINER ONLY)
 - a. With a V-Bead liner you will not use the plastic coping strips that are packed in the parts carton of your pool. You can discard those pieces, if they are included, as they only apply to pools with overlap liners.
 - b. The top of the wall of the liner has what is called a "V-Bead" welded onto it. Simply open up the bead with your fingers and hang it directly on top of the pool wall. When this is done properly, the only portion on the outside of the pool wall is approximately 1" of the V-Bead. No printed liner material is actually going over the top of the wall to the outside of the wall.
 - c. Make sure the bead is on evenly around the entire pool, and that the liner is hanging straight down from the top of the wall. The liner should not have creases in it because it is twisting around the pool. If the liner is twisting, it is because it is not sitting properly in the pool. Make necessary adjustments before proceeding.
 - NOTE: Some liners may fit very tightly, it is better to install uprights, top plate and top ledge before going onto next step. See Section 4.




<u>^</u>

Remember: Do not trim off the excess liner. (If the liner ever needs to be removed, trimming the liner will make re-installation very difficult.) Instead, roll up any excess liner and tape it in place near the top of the pool wall.

4. Fasten the liner place (BEADLOCK/SNAPBEAD LINER ONLY)

- a. With a snap bead liner you will not use the plastic coping strips that are packed in the parts carton of many pools. You can discard those pieces (if they are included). Instead, you should have received a beaded liner track (referred to as a "coping bead receiver" in this image).
- b. The beaded liner track should be installed onto the pool wall all of the way around the pool. These pieces should be as close together as possible. Leaving spaces between bead tracks can cause liner problems later on.
- c. Once all of the beaded liner track is on the wall, you can snap the liner bead into the beaded liner track at four random points around the pool. After that is done, and you are satisfied with how the liner is situated within the pool, you can continue snapping the remainder of the liner into place around the pool.
- d. Go around the entire pool again making certain that the liner is securely snapped into the track. This is important to confirm so that the liner does not pull out while under the pressure of being filled with water.
- NOTE: Some liners may fit very tightly, it is better to install uprights, top plate and ledge before going onto next step. See Section 4.

5. Proceed to Section 4 -Assembling the Pool Frame







Section 4

Pool Component Installation Manual Installing the Top Ledges & Uprights

A. Attach your Uprights and Top Ledges


1. Continue filling your Pool

- a. Continue filling your pool with water. Do not put in more than 12" (30 cm) of water until the top ledges and vertical uprights are all attached.
- b. Keep working on the top ledges and uprights while the pool fills.

• See the drawing on the next page for an overview of all the parts used to install the uprights, top ledges and ledge covers.

2. Install the Uprights

- a. Line up the bottom of one upright (key 1) with the two small tabs on one base plate (key 2). The tabs must be on the **inside** of the upright.
- b. Line up the screw holes and fasten with one self-tapping screw on each side (key 3).




 \bigcirc

Hint:

Use the ridges in the pool wall to make sure the upright is straight up and down.


- c. Hook a top plate (key 4) over the top edge of the pool wall (key 5). Place the top plate down over the top of the upright with the tabs on the **inside** of the upright. Make sure the upright is straight up and down.
- d. Line up the screw holes and fasten with one self-tapping screw on each side and one on the front (key 6).
- e. Repeat the last four steps for each of the uprights around the pool wall.



5. I

f. Adjust all the top ledges to line up ev.

No Diving or Jumping. 🛞 Observe all Safety Rules.





3. Install the Top Ledges (Straight Section)

- a. Install the side ledges between the buttress. Use hole 'A' and line up all of the holes as shown in diagram 5. Fasten throught the two oval holes to the top plate below with two self-tapping screws (key 9). Do not tighten any of the screws yet. Leave the screws slightly loose until all the top ledges are in place. Make sure the uprights are aligned straight up and down (Note: the 12' x 18' pool does not have side ledges).
- b. Verify the remaining vertical as shown in this Section 4.

4. Install the Top Ledges (Transition Section)

a. Important: the four transition A top ledges are mitred at the ends. Only the end of the transition A top ledge that is over a buttress will fasten into the hole marked 'B' in the top plate, as shown in diagram 4. For the rest of






the end ledges, use hole 'A' and line up all of the holes as

shown in diagram 5. Fasten through the tow oval holes to the top plate below with two self-tapping screws (key 9).


Do not tighten any of the screws yet. Leave the screws slightly loose until all the top ledges are in place.




- b. IMPORTANT: if any of the verticals are not straight up and down, adjust the base plate and bottom end of the vertical side to side as required by gently tapping on the base plate with a hammer and a block of wood. If you need to adjust the top of the vertical, you may need to remove the top plate first or else the wall and the liner could be dammaged.
- c. Check the length of the second transition A top rail before you fasten it. If the end of the transition rail overlaps the side rail, it needs to be cut; if the oval holes of the transition rail overlaps the side rail, it needs to be cut; if the oval holes of the transition rail do not match the holes in the top plate, you must drill new holes. (Note: the 12' x 18' pool does not have side rails, any overlap will be over the adjacent transition rail). In the case that the transition rail seems to be too short, you must pull the rails you just installed so the end of the transition rail can be attached to the top plate. The oval holes provide approximately 2" (51 mm) adjustment at each end of the pool.
- c. Repeat steps (b) and (c) for the other side of the pool.

5. If the transition rail needs to be drilled and/or cut follow these steps:

- a. Temporarily unscrew the end of the side rail that is next to the transition rail. (Note: the 12' x 18' pool does not have side rails)
- b. Place one end of the transition rail (key 8) underneatht the side rail.
 (Note: for the 12' x 18' pool place one end above the other transition rail). Place the other end ovver the first vertical on the round end of the pool and temporarily fasten this end midway of the adjustment provided by the oval holes. If you have a 12' x 18' pool, jump to step (k) now.




c. With the end of the side rail on top of the transition rail, mark two dimension 1/2" (13mm) and 1-1/8" (29mm) away from the end of the side rail. Then temporarily unscrew the other end of the side rail and move it to draw the lines X and Y. The first line X is parallel to the end of the side rail, 1/2" (13mm) away. This will be the line you will cut



along to shorten the transition rail. The seconde line \mathbf{Y} is also parallel to the end of the side rail, 1-1/8" (29mm) away. this will be the line that the new 1/4" (6mm) screw holes lie on.

- d. To mark the locations of the 1/4" (6mm) screw holes, draw two lines through the centres of each of the two oval holes, parallel to the length of the rail, to intersect the line Y. The intersection of these lines will determine the locations of the new 1/4" (6mm) screw holes that need to be drilled.
- e. If you pool calls for a support plate, drill another 1/4" (6mm) hole 1-1/2" (38mm) or 2-1/8" (54mm) toward the inside of the pool along the line Y. Measure the distance on your pool.





- f. Remove the transition rail and drill the 1/4" (6mm) holes using the marks that lie on the line **Y**.
- g. Cut the transition rail along the 1/2" (13mm) line **X** using a hacksaw (use a blade with at least 32 teeth per inch).
- h. Fasten the side rail and the tranistion rail in place.
- i. Repeat steps (a) to (h) to install the top rails at the other end of the pool.
- j. Continue with with Step 4 in this Section 4.



6. Install the Ledge Covers

- a. Loosen the front screw used to secure the top plate to the upright.
- b. Place a bottom ledge cover against an upright as shown in diagram 1.
- c. Slide the bottom ledge cover upwards until the slot on the ledge cover rests under the screw.
- d. Tighten the screw and repeat for the other uprights.
- e. Coat all showing screw heads with clear outdoor varnish.
- IMPORTANT: When installing the top ledge cover, ensure the front lip of the ledge cover is over the top lif of the bottom ledge cover.








B. Fill your Pool with Water

1. Finish filling the pool

- a. Turn off the vacuum and carefully remove it from the pool.
- b. Fill the pool with water to 2" (5cm) below the lowest opening. Make sure you remove any creases from the liner in the bottom of the pool before the water level gets too high.
- c. While the pool is filling, remove the nails that were holding the bottom rails in place.
- d. Your pool is now installed. You must now install the filter and pump, the skimmer and water return inlet.Please follow the installation instructions that come with these products.



Important:

it up.

Caution:

Before making any openings in the liner, fill the pool

with 60cm (24") of water to stretch the

liner fully. When filling

your pool, begin with a garden hose until there is about 30 cm (12") of water in the pool. This will allow the liner to stretch gradually. You can then use a heavier flow to finish filling

Make sure that your pool is round, do not assume that by filling up the pool that this will help the pool to place itself into a perfect round circle. Ensure that it is round before filling up the pool with water.

IMPORTANT SAFETY INFORMATION:

Please refer to the safety page at the beginning of this instruction manual. You must follow the rules and information regarding placement of safety stickers on your pool.



